

Changing the graphics on Rollal and Rollall Slide in units

Important - Do not let go of the top bar unless the locking pin is in place. Keep a firm grip on the top bar when pulling the graphic out or sliding it back in. Letting go of the top bar may damage the mechanism and or graphic.

Remove old graphic



Position yourself in front of unit with slot on the right hand side. Roll up graphic as far as it will go. Prepare to insert the pin which locks the spring mechanism.



Rest graphic on top of unit as shown & apply pressure by pushing away from you. Insert locking pin in end plate. If pin does not insert, ease graphic in and out by a few mm until it does.



Slide old graphic out through slot in end plate.

Replace new graphic



Slide new banner in through slot in end plate. Push it all the way in to avoid it catching when you release spring.



Hold the banner and remove the locking pin. (Keep in a safe place). If pin is stiff rotate through 90 degrees

Let the banner slowly roll into the cassette. Do not let go of graphic as this could cause damage.

EXPOLITE